



INSTRUCTION FOR INSTALLATION Waterless Urinals

In general: The height of the drain should be approx. 400 mm beginning from the ground (wall junction DN50). In case of "refitting" a plumber should clean the tubes before the assembly of the new urinal starts. No "pressure" and no "vacuum" should be in the drainpipe system (according to standard).

Preparation: Turn off the water, and lock up the old feed pipe. If there is any electronic, terminate the power cable! Now the old urinal can be dismantled (tubing cleaning recommended) – then control the seal of the draining sleeve. Grease the draining sleeve.

Assembly: Cut of the pipe with sleeve professionally to the correct length and add 4 cm on both sides (~~size pipe with sleeve~~ 50 mm - not included in the scope of supply).

Grind the pipe diagonally on the pipe side, so it can slip easily into the rubber washer and put in the urinal afterwards, align the urinal in the correct position and make marks on the wall (assembly holes). Remove the urinal from the wall and install the mounting plate device concentrically within the marking. (CERATUR urinal: please use the drilling template).

Connect the urinal again with the discharge pipe and put it on the mounting plate. Now tighten laterally the screws with the plastic supplements.

If necessary put a silicone joint (silicone fugue) around the basin and on lower surface 10 cm release. Fill the Hellbrok siphon-filter with water and put in the siphon-cartridge according to the description into the urinal.

Cleaning instructions: Renergise Urinals can be cleaned easily with a sponge or soft brush (as conventional toilet facilities). In addition we recommend our Renergise cleaner Super Plus Antibacterial.

The Renergise siphon cartridge HB-1 should be exchanged after approx. 8000 – 10000 uses or if the cartridge begins to drain more and more slowly or if it is even backing up.

Functional check: As a functional check insert approx. 0,2 – 0,5 litre of water into the urinal.
