



# HB-1

(siphon cartridge)

The HB-1 siphon cartridge is made out of ABS plastic. We deliver it with a peripheral sealing ring which is made out of rubber.

## **Applying the filter**

First of all remove the siphon out of the package. Take the cartridge and moisten the sealing ring with water. Fill in approx. ½ liter of water in the cartridge. Then insert the cartridge from above in the urinal - the filter is now ready for usage.

## **Cleaning instructions:**

The Urinals should be cleaned every day with a sponge or a soft brush as conventional toilet-facilities are normally cleaned. We recommend our Super-Plus-Antibacterial cleaner. Do not use abrasive cleaners – use only liquid cleaners which are also used for goods made out of plastic or acryl.

Once a month the siphon-cartridge must be removed from the urinal to clean the ABS-housing of the urinal with Super-Plus-Antibacterial - afterwards gap 2-3 liters of water into the urinal.

## **Note:**

If you use chemicals, acids, alkalis or if you want to clean for example a pool of sick, please first remove the filter and second clean the urinal.

## **Removing the filter:**

Before you remove the filter fill in approx. 0,5 - 1 litre of water into the cartridge, so that remaining parts get flushed out.

Take the removal key and put the nose from the top of the key into the openings of the siphon filter. Turn the key until it engages - now pull the filter out while turning it at the same time. Keep the siphon filter sideways and put it in a plastic bag to dispose it – if you clean the filter, it may also be recycled.

If there are light urine deposits in the housing of the urinal, you can easily remove the same with a soapy solution and toilet brush.